

AUX

COMMERCIAL AIR CONDITIONER



TECHNOLOGY LEADS INTELLIGENT LIFE

AUX
COMMERCIAL AIR CONDITIONER

AUX HEAT PUMP ---AC Freedom



TECHNOLOGY LEADS INTELLIGENT LIFE

Part 1

AC Freedom download and register

Part 1. AC Freedom download and register

AC Freedom APP Download:

① Scan code to download AC Freedom



Android




IOS

Part 1. AC Freedom download and register



AC Freedom APP Account registration:

- ① Click “Sign up”
- ② Agree “PRIVACY POLICY”
- ③ Fill in the country and email address
- ④ Fill in the verification code and password



Part 2


Heat pump unit networking

Part 2. Heat pump unit networking



Follow the steps to add device:

③ Reset the wifi network settings




Part 2. Heat pump unit networking

AUX

Follow the steps to add device:

④ After “Settings”, automatically jump to the mobile phone network setting interface, select AP address “AC_XXXX” group.

(Bluetooth connection, Automatically match nearby heat pump without need to select AP address)



Part 3


AC Freedom Operation instruction

Part 3. AC Freedom Operation instruction



Follow the steps to operate device:

- ②③ Double zone heating and cooling control
- ④ DHW control




Part 3. AC Freedom Operation instruction



Follow the steps to set running schedule:


④⑤ Set the weekly operating status and start-stop time of the unit.



Part 3. AC Freedom Operation instruction




Follow the steps to query and set device parameters:



Part 3. AC Freedom Operation instruction

Follow the steps to query and set device parameters:

④⑤ Share the device with other users.





Part 3. AC Freedom Operation instruction






Follow the steps to query and set device parameters:

⑥⑦ Query parameters, query faults, and reset factory settings.

⑥



⑦





Part 3. AC Freedom Operation instruction







Follow the steps to query and set device parameters:

⑧⑨ Query IDU, ODU, capacity, COP and program version, etc.

⑧




⑨



Part 3. AC Freedom Operation instruction




Follow the steps to select language:



Part 3. AC Freedom Operation instruction



Follow the steps to manage unit operation permissions:



AUX
COMMERCIAL AIR CONDITIONER

THANKS

TECHNOLOGY LEADS INTELLIGENT LIFE